



Clear Rocker Panel Guards

Prime Clear Rocker Panel Guards are made from Prime Paint Protection Film. It is a rugged, clear, polyurethane plastic employing a clear-coat finish for maximum shine and durability. Once applied, the material is virtually invisible yet helps prevent chipping, scratching and scuffing to the protected surface.

Directions:

1. Ensure that the surface is clean and dry. It is preferred to install Prime Clear Protection Film in the shade and not direct sunlight
2. Fill a clean spray bottle with water and add 2-3 drops of dishwashing liquid. Shake well.
3. Cut an appropriate size piece of film from the roll using a pair of scissors.
4. Peel the backing paper from the film while wetting the soap and water solution
5. Slide into place on the rocker panel with the adhesive side down. More soapy water may be added if necessary to move the part easily.
6. Squeegee the water from beneath the film using the supplied squeegee.
7. Wrap the edges of the Rocker Guard material around the back of the panel to complete the installation.

Prime Rocker Panel Guards are designed to withstand years of wear and tear, but can be easily removed if needed.