



**Directions**

1. Carefully unwrap all Prime Heat Display components
2. Take the individual glass pieces out that you intend on tinting, by removing the top piece. Simply lift the top off and place is aside.
3. Clean and prep the glass as you would a regular window to be tinted
4. Tint the glass using your preferred Prime window films.
5. Reinstall the glass into the display by sliding the glass into the appropriate slots.
6. Locate the premade sticker pack with the various VLT's and Product Lines.
7. Install the stickers in the bottom right corner of the glass on the corresponding VLT
8. Once you have finished installing the glass and stickers – using the supplied cord, insert the female plug into the display and the male plug into a wall outlet.
9. Press the button on the display and the lights will illuminate